



HEAVY DUTY STUB AXLES – 2004-2006 GTO

Part # AS001-L and AS001-R

1. Lift vehicle and support with stands under cradle allowing rear wheels to hang. Set emergency brake.
2. Using a 5/16" or 8mm Allen head socket, remove all 6 bolts that attach the CV shaft to the stub axle. Pull the CV away from the stub axle, allowing the axle to hang.
3. Using a prybar, pry the factory stub axle out of the differential. They are retained by spring clips and only require a slight amount of pressure to remove.
4. Using a pick or small screwdriver, transfer the spring clip from the factory stub axle to the BMR HD stub axle.
5. Re-install the HD stub axle using a rubber mallet to set the axle.
6. Apply blue Loctite to the threads of the mounting hardware and re-install the CV shaft. It may be necessary to lift the wheels in order to get the bolts started.
7. Torque all bolts to 45 ft/lbs.
8. Repeat steps 2-7 on opposite side. Lower vehicle.



Actual product may differ slightly in appearance

WWW.BMRFABRICATION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.